

100MHz VF CONVERTER
N2VF-1H
USER'S MANUAL

#3503 (rev.1) 2016.06.10



TSUJICON APPLICATION OF ELECTRONIC DEVICES

TSUJI ELECTRONICS CO.,LTD

3739 Kandatsu-machi Tsuchiura-city
Ibaraki-Pre 300-0013 Japan
Phone +81-(0)29-832-3031
Fax +81-(0)29-832-2662
URL <http://www.tsujicon.jp>
E-mail info2@tsuji-denshi.co.jp

100MHz VF converter N2VF-1H

User's Manual [Rev.1]

1. Feature

N2VF-1H is the 100MHz 2CH V-F Converter that is housed in a NIM-1UNIT case. It has the four-levels amplification factor switch and the polarity selector switch.

N2VF-1H is easy to be monitored.

i.e., the over-range and polarity are displayed on LED and also outputted as open-collector outputs.

Therefore, V-F conversion is always performed at the optimum conditions.

2. Specification

Channels	2CH
Input Range	-10V/-5V/-2.5V/-1V/+1V/+2.5V/+5V/+10V
Input	Single-end
Input Impedance	1M Ω
Output Range	100MHz/50MHz/25MHz/10MHz
Output	TTL level ※ Please use 50 Ω termination to reduce the reflected wave.
Conversion Accuracy	$\pm 0.01\%$ FS
Input Sampling Frequency	1MHz
Response	10 μ s or less
Input Connector	BNC connector
Output Connector for Frequency	LEMO connector (equivalent to EPL00250NTN)
Over-Range output	Open collector (normally close), isolated
Over-Range output Connector	BNC connector
Power supply	+12V/200mA, +6V/600mA
Case	NIM-1UNIT


3. Before using

Before using, please power about 2 hours on for a warm-up.

The frequency deviation becomes large, if warm-up has not been made.


4. Usage

4-1. Front panel



- ① CH1 Scale over LED
LED lights on when the input level exceeds conversion level.
- ② CH1 Input polarity LED
LED lights on if the voltage input polarity is different from the setting.
- ③ CH1 Input voltage range select SW
Select input voltage range.
- ④ CH1 Output frequency range select SW
Select output frequency range.
- ⑤ CH2 Scale over LED
LED lights on when the input level exceeds conversion level.
- ⑥ CH2 Input polarity LED
LED lights on if the voltage input polarity is different from the setting.
- ⑦ CH2 Input voltage range select SW
Select input voltage range.
- ⑧ CH2 Output frequency range select SW
Select output frequency range.
- ⑨ CH1 Input connector (voltage, BNC)
- ⑩ CH1 Polarity select slide-SW
NOM: (+), REV: (-)
- ⑪ CH2 Input connector (voltage, BNC)
- ⑫ CH2 Polarity select slide-SW
NOM: (+), REV: (-)
- ⑬ CH1 Output connector (frequency, LEMO, LVTTTL level)
- ⑭ CH2 Output connector (frequency, LEMO, LVTTTL level)

4-2. Rear panel



- ① CH1 Scale over output connector (BNC)
Open collector output. It is isolated from the internal circuit.
Output becomes off if the voltage input is over than the setting.
(normaly close)
- ② CH2 Scale over output connector (BNC)
Open collector output. It is isolated from the internal circuit.
Output becomes off if the voltage input is over than the setting.
(normaly close)
- ③ Changeover switch for choosing isolation or common between
NIM GND and the internal circuit GND.
FLOTING: isolation, G.COMMON: common