

2CH PULSE MOTOR CONTROLLER  
UPM2C-01

USER'S MANUAL

(3168 rev.7)



APPLICATION OF ELECTRONIC DEVICES

**Tsuji Electronics Co., Ltd.**

Head Office/3739 Kandatsu-machi Tsuchiura-city

Ibaraki-Pre. 300-0013 Japan

Phone +81-(0)29-832-3031

Fax +81-(0)29-832-2662

URL <http://www.tsujicon.jp>

E-mail [info2@tsuji-denshi.co.jp](mailto:info2@tsuji-denshi.co.jp)

# Contents

<b>Contents</b> .....	<b>1</b>
<b>1 Abstract</b> .....	<b>1</b>
1-1 Feature .....	1
1-2 Controller composition .....	2
1-3 Cconnection diagram.....	2
<b>2 Appearance</b> .....	<b>3</b>
2-1 Front & Rear panel.....	3
<b>3 Connection with outer equipment</b> .....	<b>4</b>
<b>4 Setting USB communication</b> .....	<b>5</b>
4-1 Outline .....	5
4-2 Preparation.....	5
4-3 Connecting test.....	5
<b>5 The basic operations</b> .....	<b>6</b>
5-1 About speed setting .....	6
5-2 Short summary of driving parameter setting method.....	7
<b>6 The detail of communication commands</b> .....	<b>10</b>
6-1 Command to read out of motor status .....	10
6-2 GP-IB simulated SRQ command .....	12
6-3 Motor control command .....	12
6-4 Motor parameter setting and Reading command commentary .....	18
6-5 Current position setting and Reading command commentary .....	21
6-6 Commands related to HOLD OFF.....	21
6-7 Command for set and read out limit switch data parameters .....	22
6-8 Other commands.....	26
6-9 The initialization of setting data.....	26
<b>7 Continuous drive mode (from V1.03)</b> .....	<b>27</b>
7-1 About Continuous drive mode .....	27
7-2 About data format .....	27
7-3 Move mode setting.....	28
7-4 Data input .....	28
7-5 Continuous motion control.....	29
7-6 Setting data initialization .....	30
<b>8 Dual-Axis Complementary Drive</b> .....	<b>31</b>
8-1 Outline .....	31
8-2 Line Approximation Movement.....	31
8-3 Complementary Arc Movement.....	32
8-4 Waypoint Complimentary Arc Movement .....	33
8-5 True circle movement with complemented waypoint .....	34
<b>9 Firmware version up</b> .....	<b>35</b>
<b>10 Data1 “SPEED code”</b> .....	<b>37</b>
<b>11 Data2 “Acceleration / Deceleration rate”</b> .....	<b>38</b>
<b>12 Performance and Specifiation</b> .....	<b>39</b>

# 1 Abstract

---

## 1-1 Feature

UPM2C-01 is the succeeding model which extracted the communication function of NPM2C-01 only to USB. Control command is upward compatible with NPM2C-01. The parameter which can be set is also extended and it is also miniaturized. It can control immediately only by connecting with USB cable because a power supply is supplied directly from a USB port of PC. It is controllable with the control software of NPM2C-01 because the command of NPM2C-01 can be used.

The main extending points and the changed part from NPM2C-01 are as follows.

- Extension of the number of pulses which can be treated (24bit → 32bit)  
(-8,388,607 to +8,388,607) → (-2,147,483,647 to +2,147,483,647)
- Extension of the number of output pulse frequency  
(1PPS to 100KPPS) → (1PPS to 5MPPS)
- It corresponds to constant-speed drive and sigmoid drive other than trapezoidal drive.
- You can upgrade of firmware (ROM) by USB communication.
- The addition of new commands.
- A large small weight saving and price reduction.

The function of NPM2C-01 and PM2C-06 is also succeeded.

- You can control characteristics of two pulse motors, such as HSPD, MSPD, LSPD, RATE and LMSW individually.
- You can start two motors at a time.
- There are relative position movement, absolute position movement and continuation movement in the move method.
- You can stop the motor by signal from the limit switch and stop command. Slowdown stop and sudden stop can be chosen in each stop procedures.
- Configuration data and positioning data are saved by battery backup.

### Caution


This device consumes 250mA on an average, and consumes about 300mA at the maximum. When you use it, please connect directly with PC or connect a USB hub with AC power supply. When it is used with other USB device which consumes current on a PC, this device does not start due to a shortage of current or other USB device may be affected. In that case, please use optional AC adapter.

Be sure to turn off the driver before connecting the USB cable.


Make sure that the UPM2C-01 power lamp lights up before turning on the driver.

### 1-2 Controller composition

< Controller diagrammatic illustration >




### 1-3 Connection diagram




LS : Limit Switch

## 2 Appearance

### 2-1 Front & Rear panel



1. Power LED    2. ACCESS LED    3. USB connector    4. Sensor power supply




5. LS input connector    6. Pulse output connector

No.	Name	Function
1	POWER LED	Power LED lights when the power is on. There is no power switch. Power is applied to this unit when you connect a USB connector.
2	ACCESS LED	Access LED lights on according to the busy state of internal motor IC. Moreover, when updating the firmware, LED announce you an internal state by blink and lighting.
3	USB connector	The connector for USB communication. Connector shape is USB-B type. Be sure to turn off the motor driver unit before connecting the USB cable. Make sure that the UPM2C-01 power lamp lights up before turning on the driver unit.
4	Sensor power supply	Power input connector of EIAJ-4 size for 12 V DC. When you supply 12 V DC to LS, or when stable power supply is required, please connect an AC adapter of 12 V DC (T3168AC) to this connector.
5	Limit sensor input connector	Please connect the external limit sensor signal to this connector. Connector shape is DE9P (M) type. Since the interval of a connector is 38mm, please use a D-sub hood with a size of 35 mm or less.
6	Pulse output connector	Pulse signal is output from this connector. Connector shape is DE9S (F) type.

# 3 Connection with outer equipment

Connection cables are recommended to be shielded twist pair cable. (more than 0.2mm<sup>2</sup>)



(NOTE)

Connector shell size of DE9P and 9S is varied from each maker's.

Please use the shell whose width is 35mm or less.

DE-C1-J6 (JAE), XM2S-0911 (OMRON) and HDE-CTF (HIROSE) are possible to be used.

\* H.OFF output has been changed from line driver to open collector since shipping in 2016.  
Connection cable can be used continuously.

## 4 Setting USB communication

---

### 4-1 Outline

A driver software used in UPM2C-01 to do the USB communication that considered a USB port to be a COM port. For the reason, there is the necessity of downloading from our homepage and installing driver software. However, there is no necessity of installing driver software when USB communication has been established with other products of our companies, such as NPM2C-01 and NCT08-01B.

### 4-2 Preparation

1. VCP driver software for USB operation is downloaded from our web server.
2. Switch on a UPM2C-01 and connect USB cable, then there will be message box that shows "New hardware device was found".
3. According to PC directions, specify the folders of downloaded driver software.
4. When the driver software installs are done, open the "Control Panel" (START → Control Panel), click the "System" icon. Then property display of system appears.
5. Select the "Device Manager". Confirm the USB Serial Port (Com\*) number in the tree between Port display.
6. Select the USB Serial Port (Com\*), click advanced in port setting display. It's possible to change COM Port number.

### 4-3 Connecting test

Launch RS-232C communication software such as hyper-terminal including PC. Set COM port number which is known in previous item, it is need to check communication line is available or not. In this case it's no need to set baud rate. Send the command data "VER?", then get the reply such as "1.00 12-03-28 UPM2C", there is no problem for communication.


## 5 The basic operations

There is no operation panel on a UPM2C-01, so all the operations, a setup of various parameters, and a state check are performed by USB communication. If “Setting USB communication” of the preceding clause is completed, various parameters will be set and a motor will be operated.

### 5-1 About speed setting


High speed (HSPD), middle speed (MSPD), low speed (LSPD) and acceleration rate is set individually for each channel. Acceleration and deceleration method have the three modes, “Const”, “Trape”, and “Schar”.

#### (1) Constant drive (Const)



Motor drives at MAX speed as soon as drive execution, and stops immediately as soon as stop operation. Too fast drive speed causes motor step out.  
Low speed drive is always constant drive at all drive mode.

#### (2) Trapezoidal form acceleration drive (Trape)




Acceleration operation is carried out until it will reach MSPD or HSPD by making LSPD into initial velocity, if a motion command is executed.

When a stop command is input, the motor starts deceleration. And the motor stop when speed reached LSPD. Acceleration and deceleration curve become rapid, and time to reach maximum speed shortens so that Rate value shown by acceleration and deceleration code (See page 64) is large.

Large value of "LSPD" may not make smooth start of the motor.



(3) S shaped form acceleration drive (Schar)



Although it is fundamentally the same as trapezoidal form acceleration drive, the velocity change at the time of acceleration and deceleration start and the time of acceleration and deceleration stop is performed according to S shaped form approximated to the parabola.

Large value of "LSPD" may not make smooth start of the motor.

The start region A and the stop region B are fixation. When LSPD is more than or equal  $LSPD + 4000pps$ , it calculates automatically so that a curve may become smooth.

### 5-2 Short summary of driving parameter setting method

By inputting the following commands, parameters such as speed can be changed. When the ACCESS lamp has gone out (when the drive is not performing), please input the command which sets a parameter.

\* About communication command

The format of command is ASCII data, and the delimiter is CR + LF (0DH + 0AH). After receiving CR + LF, command interpretation begins. When the unit receives the command without delimiter, the receiving data will be considered to be a front part command characters. In this case, followed commands will be lost, and command interpretation will be impossible. When sending commands, "CR + LF" must be added at the end of the command, though the "CR + LF" are omitted in the command explained below.

x: 0/Channel A 1/Channel B d: Decimal

	Command description	Command	Remarks column
<b>Driving parameter setting method</b>			
1	Speed selection default : MSPD	SPDxH SPDxM SPDxL	
2	Read out the set speed of channel x.	SPD?x	The replay is HSPD, MSPD or LSPD.

x: 0/Channel A 1/Channel B d: Decimal

	Command description	Command	Remarks column
3	Driving speed setting The setting unit is pps (pulse per second). default : HSPD = 3700 MSPD = 650 LSPD = 10	SPDHxddddddd	1 to 5,000,000.
		SPDMxddddddd	
		SPDLxddddddd	
4	Read out the driving speed setting	SPDH?x	The reply is dddd..... Unit is PPS.
		SPDM?x	
		SPDL?x	
5	Accerالاتon and deceleration parameters setting default : 13	RTExxxx	0 to 115
6	Read out accerالاتon and deceleration parameters	RTE?x	The reply is ddd.
7	Motor parameters setting default : 1ABC = 1010 (hold off, trapezoidal, Pulse-Pulse)	SETMTx1ABC	A : 1/hold on, 0/hold off B : 0/constant, 1/trapezoidal, 2/ S character C : 0/Pulse-Pulse, 1/Pulse-Direction
8	Read out motor parameters	SETMT?x	The reply data is in order 1ABC.
9	Limit switch data parameters setting default : 01110000 (Digital limit switch disable, H.P LS Enable, CCW LS Enable, CW LS Enable, H.P LS set N.O, CCW LS set N.O, CW LS set N.O)	SETLSxDYYYY0yyy	D:0/Degital LS disable 1/Enable YYY:0/LS disable, 1/Enable yyy:0/LS set is N.O, 1/N.C
10	Read out limit switch data parameters	SETLS?x	The reply is DYYYY0yyy.
11	Set the digital limit data to CW side default : +1,000,000	FLx±ddddddddd	-2,147,483,647 to +2,147,483,647
	Set the digital limit data to CCW side default : -1,000,000	BLx±ddddddddd	-2,147,483,647 to +2,147,483,647
12	Read out digital limit data to CW side setting	FL?x	The reply is ±ddddddd (decimal number).
	Read out digital limit data to CCW side setting	BL?x	The reply is ±ddddddd (decimal number).

x: 0/Channel A 1/Channel B d: Decimal

	Command description	Command	Remarks column
<b>Driving execution method</b>			
13	Absolute index scan	ABS <sub>x</sub> ±ddddddddd	-2,147,483,647 to +2,147,483,647
14	Relative index scan	REL <sub>x</sub> ±ddddddddd	-2,147,483,647 to +2,147,483,647
15	Accelerative scan	SCANP <sub>x</sub>	CW direction
		SCANN <sub>x</sub>	CCW direction
16	Stop command both of channel	ASSTP	With deceleration
		AESTP	Without deceleration
<b>Localization method</b>			
17	Current position data setting	PS <sub>x</sub> ±ddddddddd	-2,147,483,647 to +2,147,483,647
18	Read out the current data of motor channel x.	PS? <sub>x</sub>	The reply is ±ddddddd (decimal number).
19	Read out the details of motor state	STS?	The format of reply data is like this.  R01/AB/CC/HHJJ/ ±aaaaaa/±bbbbbb  For details, refer to Chapter 6.

## 6 The detail of communication commands

---

### 6-1 Command to read out of motor status

x: 0/Channel A 1/Channel B d: Decimal  
(old): NPM2C-01 compatible command

Command	Reply								
STS?	<p>Read out current motor operation status.</p> <p>Reply: R01/&lt;AB&gt;/&lt;CC&gt;/&lt;HHJJ&gt;/&lt;±aaaaaaa&gt;/&lt;±bbbbbb&gt;</p> <p>&lt;AB&gt; A:ch A, B:ch B P/ Moving for CW direction S/ Stopping N/ Moving for CCW direction</p> <p>&lt;CC&gt; Hold off and LS status by hex. When these signals are activating, its bits stands 1.</p> <table border="0"> <tr> <td>b7: ch A HOLD off</td> <td>b3: ch B HOLD off</td> </tr> <tr> <td>b6: ch A HP LS</td> <td>b2: ch B HP LS</td> </tr> <tr> <td>b5: ch A CCW LS</td> <td>b1: ch B CCW LS</td> </tr> <tr> <td>b4: ch A CW LS</td> <td>b0: ch B CW LS</td> </tr> </table> <p>&lt;HHJJ&gt; HH:ch A, JJ:ch B Indicate current motor status by 2 digit hex.</p> <p>b7: Emergency stop command executed. b6: Stop with deceleration command executed. b5: Stopped by LS signal. b4: Command error</p> <p>b3: Decelerating b2: Accelerating b1: Motor is moving. b0: Driving or dealing with command.</p> <p>&lt;±aaaaaaa&gt; &lt;±bbbbbb&gt; Displaying current position of each motor with signed 7 digit decimal. Digit is increased if data is more than 10 million.</p>	b7: ch A HOLD off	b3: ch B HOLD off	b6: ch A HP LS	b2: ch B HP LS	b5: ch A CCW LS	b1: ch B CCW LS	b4: ch A CW LS	b0: ch B CW LS
b7: ch A HOLD off	b3: ch B HOLD off								
b6: ch A HP LS	b2: ch B HP LS								
b5: ch A CCW LS	b1: ch B CCW LS								
b4: ch A CW LS	b0: ch B CW LS								

x: 0/Channel A 1/Channel B d: Decimal  
 (old): NPM2C-01 compatible command

Command	Reply
STSx?	<p>Read out the specified CH motor data.</p> <p>Reply: Rx/&lt;A&gt;/&lt;CC&gt;/&lt;HH&gt;/&lt;±aaaaaaa&gt;</p> <p>&lt;A&gt;            P/ Moving for CW direction            S/ Stopping            N/ Moving for CCW direction</p> <p>&lt;CC&gt;            Hold off and LS status by hex.            When these signals are activating, its bits stands 1.</p> <p>&lt;HH&gt;            Indicate current motor status by 2 digit hex.</p> <p>&lt;±aaaaaaa&gt;            Displaying current position of each motor with signed 7 digit decimal. Digit is increased if data is more than 10 million.</p> <p>Data format is the same as “STS?” except [x].</p>
STSM?	<p>Read out contents of control IC (MCC06)’s status.</p> <p>Reply: aaaa/bbbb</p> <p>Regarding 2channels that are displayed, MCC06's status is displayed in hexadecimal four-digit.</p>
(old)S2x1	<p>Read out contents of control IC (MCC06)’s status by 2 digit hex.</p> <p>Reply: RXHH</p> <p>Data format is the same as HHJJ of “STS?”.</p>

## 6-2 GP-IB simulated SRQ command

When the motor stops moving, GP-IB simulated SRQ signal is output automatically. It can be used during motor stop state. Send form of the commands are below. The SRQ flags, which were set once before, are cleared at the SRQ send out timing.

x: 0/Channel A 1/Channel B d: Decimal  
(old): NPM2C-01 compatible command

Command	Reply
SRQ?x	Read out SRQ output flag of channel x. Reply: a a: 0/Unsetting 1/Settin
(old) S18	Read out SRQ output flag. Reply: R0H H: b1/ch B, b0/ch A
SRQx1 (old) S1x1	Set SRQ flag of channel x.
SRQx0 (old) S1x0	Clear SRQ flag set for channel x.

## 6-3 Motor control command

x: 0/Channel A 1/Channel B d: Decimal  
(old): NPM2C-01 compatible command

Command	Reply
JOGPx JOGNx	JOGPx: Motor drives one pulse to CW direction. JOGNx: Motor drives one pulse to CCW direction.
(old) S3x08 (old) S3x09	S3x08: Motor drives one pulse to CW direction. S3x09: Motor drives one pulse to CCW direction.
SPDx(L/M/H)	Select motor move speed of channel x. L/LSPD M/MSPD H/HSPD
(old) S71(L/M/H)	Select motor move speed of both channel. L/LSPD M/MSPD H/HSPD

x: 0/Channel A 1/Channel B d: Decimal  
 (old): NPM2C-01 compatible command

Command	Reply
SPD?x	Read out the motor speed setting of channel x.  Reply: LSPD/MSPD/HSPD
(old) S48	Read out the motor speed setting of both channel.  Reply: RRN03<ab> a: ch A, b: ch B a, b: 1/LSPD, 2/MSPD, 3/HSPD  Example RRN0321: Ch A is set to MSPD and ch B is set to LAPD.
SCANPx SCANNx	SCANPx: Motor drives to CW direction continuously at the above selected speed. SCANNx: Motor drives to CCW direction continuously at the above selected speed.
(old) S3x0E (old) S3x0F	S3x0E: Motor drives to CW direction continuously at the above selected speed. S3x0F: Motor drives to CCW direction continuously at the above selected speed.
CSCANPx CSCANNx	It is the same as the above command "SCANPx", "SCANNx", "S3x0E" and "S3x0F", but moves without acceleration / deceleration.
(old) S3x0C (old) S3x0D	Becareful of SPD setting value, because too fast SPD value causes motor step out.
SCANHPx SCANHNx	It is the same as the above command "SCANPx", "SCANNx", "S3x0E" and "S3x0F", except that the motor stops suddenly if the home position sensor operates.
(old) S3x1E (old) S3x1F	If you know the approximate home position, it can detect the home position in a short period of time.
SSTPx	Decelerate and stop the motor of the selected channel.
(old) S3x40	
ESTPx	Suddenly stop the motor of the selected channel.
(old) S3x80	

x: 0/Channel A 1/Channel B d: Decimal  
 (old): NPM2C-01 compatible command

Command	Reply
ASSTP	Decelerate and stop the motors of both ch A and ch B.
AESTP	Suddenly stop the motors of both ch A and ch B.
ABSx±ddd...d ABSxBddd...d	<p>Move the selected motor by absolute position specification.            If you enter B, the motor moves while performing backlash correction.</p> <p>ddd...d: -2,147,483,647 to +2,147,483,647</p> <p>Example            ABS03000: Move the motor of ch A to the position of +3000.            ABS1B-1500: Move the motor of ch B to the position of -1500 with backlash correction.</p>
(old) S38x±DDDDDDDDbb	<p>Move the selected motor by absolute position specification.</p> <p>±DDDDDDDD: -9,999,999 to +9,999,999 (decimal)            bb: 11/constant movement            13/acceleration and deceleration movement</p> <p>Example            S381+002000013: Move the motor of ch B to the position of +20000 with acceleration and deceleration movement.</p>
(old) S3aA±DDDDDDDD  (old) S3aA±DDDDDDDB	<p>Move the selected motor by absolute position specification.            If you enter B, the motor moves while performing backlash correction.</p> <p>a: 2/ch A, 3/ch B            ±DDDDDDDD: -9,999,999 to +9,999,999 (decimal)</p> <p>Example            S32A+0020000: Move the motor of ch A to the position of +20000.</p>



x: 0/Channel A 1/Channel B d: Decimal  
 (old): NPM2C-01 compatible command


Command	Reply
RELx+ddd...d RELxBddd...d	Move the selected motor with relative position specification. If you enter B, the motor moves while performing backlash correction.  ddd...d: -2,147,483,647 to +2,147,483,647  Example REL03000: Move the motor of ch A by +3000 pulses. REL1B-1500: Move the motor of ch B by -1500 pulses with backlash correction.
(old)S38x ±DDDDDDDDbb	Move the selected motor with relative position specification.  ±DDDDDDDD: -9,999,999 to +9,999,999 (decimal) bb: 10/constant movement 12/acceleration and deceleration movement  Example S381-002000012: Move the motor of ch B by +3000 pulses with acceleration and deceleration movement.
(old) S3aR ±DDDDDDDD  (old)S3aR ±DDDDDDDB	Move the selected motor with relative position specification. If you enter B, the motor moves while performing backlash correction.  a: 2/ch A, 3/ch B ±DDDDDDDD: -9,999,999 to +9,999,999 (decimal)  Example S32R+0020000: Move the motor of ch A by +20000 pulses.
PAUSE ON (old) S3x16	These commands are for synchronous start of motors. All motor except moving are changed standby status by “PAUSE ON” command.
PAUSE OFF (old) S3x17	If release standby staus by “PAUSE OFF” command, reserved commands are all executed.
PAUSE?	Check the motor standby status.  Reply: ON/OFF

•Backlash correction


It is a function to return to destination after moving a set pulse number extra. For example, if the corrected step number is +500, the motor move point that added +500 to destination. After that the motor return 500 steps and positioning is completed.

Backlash correction move has different behavior by plus and minus of correction and how to approach to destination from CCW direction or CW direction. Please refer below to two example.

a) A case of backlash correction is plus



b) A case of backlash correction is minus



When the automatic adjustment is effective, backlash correction move is the same as no backlash correction. When the automatic adjustment is ineffective, as soon as the motor once stops at correction value, the motor drives to destination soon.

x: 0/Channel A 1/Channel B d: Decimal  
 (old): NPM2C-01 compatible command

Command	Reply
(old) Bx±dddd	Backlash correction data set.  dddd: -9,999 to +9,999 (decimal)
(old) Bx?	Backlash correction data read.  Reply: ±DDDD: -9,999 to +9,999 (decimal)
BADJxd	Set whether backlash correction is valid or invalid.  d: 0/invalid, 1/valid
BADJ?x	Check the set value of backlash correction.  Reply: 0/invalid, 1/valid

## 6-4 Motor parameter setting and Reading command commentary

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
SETMTxabcd	<p>Set the basic characteristics of the selected motor.            In the hold off state, a hold off signal is output to an externally installed driver. When motor operation is performed in this state, automatically hold on state is set immediately before operation, and it returns to the hold off state again at the end of operation.</p> <p>a: 1/ Motor operation possible      This setting is fixed to 1.            b: 1/ hold on, 0/ hold off</p> <p>Set the motor acceleration / deceleration form.</p> <p>c: 0/ Const (Constant)            1/ Trape (Trapezoid)            2/ Character (S shape drive)</p> <p>Set the signal output form to the externally installed motor driver.</p> <p>d: 0/ Pulse - Pulse      1/ Pulse - Direction</p>
SETMT?x	<p>Read the basic setting of the selected motor. For the contents of “abcd”, refer to the section on SETMT command.</p> <p>Reply: abcd</p> <p>Example            1010: This motor is in hold off state, trapezoidal acceleration / deceleration form, Pulse - Pulse output.</p>
SPDH?x	<p>Read the HSPD value of the selected motor in PPS units.</p> <p>Reply: dddddd (An integer of 6 digits or more)</p>
(old) SPH?x	<p>Reply: Rddddd (An integer of 6 digits)</p>
(old) S4x0	<p>Read the HSPD value of the selected motor in code (See paragraph 10).</p> <p>Reply: RXHDDDD            DDDD: Code value</p>

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
SPDHxddd...	Set the HSPD value of the selected motor in PPS units. ddd...: 1 to 5,000,000 (Any number of digits)
(old) SPHxdddddd	dddddd: 000001 to 999,999 (6 digits)
(old) S39x0DDD	Set the HSPD value of the selected motor with 3 digits code. (See paragraph 10) DDD: 000 to 254 (3 digits)
SPDM?x	Read the MSPD value of the selected motor in PPS units. Reply: ddddd (An integer of 6 digits or more)
(old) SPM?x	Reply: Rdddd (An integer of 6 digits)
(old) S4x1	Read the MSPD value of the selected motor in code (See paragraph 10). Reply: RXMDDDD
SPDMxddd...	Set the MSPD value of the selected motor in PPS units. ddd...: 1 to 5,000,000 (Any number of digits)
(old) SPMxdddddd	dddddd: 000001 to 999,999 (6 digits)
(old) S39x1DDD	Set the MSPD value of the selected motor with 3 digits code. (See P21) DDD: 000 to 254 (3 digits)
SPDL?x	Read the LSPD value of the selected motor in PPS units. Reply: ddddd (An integer of 6 digits or more)
(old) SPL?x	Reply: Rdddd (An integer of 6 digits)

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
(old) S4x2	Read the LSPD value of the selected motor in code. (See paragraph 10). Reply: RXLDDDD
SPDLxddd...	Set the LSPD value of the selected motor in PPS units. ddd... 1 to 5,000,000 (Any number of digits)
(old) SPLxdddddd	dddddd: 000001 to 999,999 (6 digits)
(old) S39x2DDD	Set the LSPD value of the selected motor with 3 digits code. (See P21) DDD: 000 to 254 (3 digits)
RTE?x	Read the acceleration / deceleration rate of the selected motor with 3 digits code. (See paragraph 11) Reply: ddd (An integer of 3 digits)
(old) S4x3	Reply: RXRddd DDD: Code value
RTExddd	Set the acceleration / deceleration rate of the selected motor with code.
(old) S39x3ddd	ddd: 0 to 115

## 6-5 Current position setting and Reading command commentary

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
PS?x	Read the current position of the selected motor. Reply: ±ddd····d (Signed 7 or more digit integer)
(old) S2x0	Reply: RX±DDDDDDDD (Signed 7 digits integer)
(old) S4xPS	Reply: RX±DDDDDDDD (Signed 7 digits integer)
PSxddd...	Set the current position of the selected motor. ddd....: -2,147,483,647 to +2,147,483,647 The number of digits and the sign are arbitrary.
(old) S5xPS±DDDDDDDD	±DDDDDDDD: -9,999,999 to 9,999,999 Signed 7 digits integer

## 6-6 Commands related to HOLD OFF

x: 0/Channel A 1/Channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
HOLD?x	Read the HOLD OFF signal output state of the selected motor. Reply: ON/OFF
HOLDxON (old) S3x19	The hold off signal of the selected motor is canceled.
HOLDxOFF (old) S3x18	The hold off signal is output to the selected motor.

## 6-7 Command for set and read out limit switch data parameters

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
SETLSxdaaa0bbb	<p>Set the states of limit switch of motor channel x.</p> <p>d: Soft limit switch 0/disable, 1/enable            aaa: limit switch 0/disable, 1/enable            (From the left, HP, CCW, CW)            bbb: Contact switching 0/N.O, 1/N.C            (From the left, HP, CCW, CW)</p>
SETLS?x	<p>Read out the states of limit switch of motor channel x setted up by the above command.</p> <p>Reply: daaa0bbb</p>
LS?	<p>Read out the states of limit switch and hold off for channel A, B.</p> <p>Reply: 01AB</p> <p>A, B: Displays the state of the limit switch and HOLD OFF signals of the channel A and B in hexadecimal digit. Detail of H and h is shown below.            A bit with 1 indicates there is an output.</p> <p>b3: Hold off                      b1: CCW LS            b2: HP LS                        b0: CW LS</p>
(old) S2x2	<p>H: Read out the states of limit switch and hold off. Display with hex one digit number.</p> <p>Reply: RXH</p>
HDSTLS?	<p>Read the states of limit switch and soft limit switch.</p> <p>Reply: 01ABab</p> <p>A, B: Display the state of each limit switch of channel A and B in hexadecimal digit.            a, b: Display the state of each soft limit switch of channel A and B in hexadecimal digit.</p> <p>b3: NO USE                      b1: CCW LS            b2: HP LS                        b0: CW LS</p>



x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
(old) LSEN?	<p>Read the ENABLE/DISABLE of limit switch of the each channels with hex two digits number.</p> <p>Reply: RHH</p> <p>HH: 0/ DISABLE, 1/ ENABLE</p> <p>b7: Channel B, HP limit switch            b6: NO USE            b5: Channel B,CCW limit switch            b4: Channel B, CW limit switch</p> <p>b3: Channel A, HP limit switch            b2: NO USE            b1: Channel A,CCW limit switch            b0: Channel A, CW limit switch</p> <p>Example            RE: all limit switches are enabled.</p>
(old) LSENHH	<p>Set the ENABLE/DISABLE of limit switch of each channels with hex two digits number.</p>
(old) LSIV?	<p>Read the contact of limit switch of each channels with hex two digits number.</p> <p>Reply: RHH</p> <p>HH: 0/ N.O 1/ N.C</p> <p>b7: Channel B, HP limit switch            b6: NO USE            b5: Channel B,CCW limit switch            b4: Channel B, CW limit switch</p> <p>b3: Channel A, HP limit switch            b2: NO USE            b1: Channel A,CCW limit switch            b0: Channel A, CW limit switch</p> <p>Example            REF: all limit switches are N.C.</p>

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
(old) LSIVHH	Set the contact of limit switch of each channels with hex two digits number.
STOPMDxa	Set stop method when limit switch is detected.
(old) S39x5a	a: 0/ Deceleration stop, 1/ Sudden stop
STOPMD?x	Read stop method when limit switch is detected. Reply: a
(old) S39x6HH	<p>Set various flags.            HH: Hex two digits number.</p> <p>b7: NO USE            b6: NO USE            b5: Automatic backlash adjustment            b4: Soft limit switch state</p> <p>b3: NO USE            b2: NO USE            b1: NO USE            b0: Limit switch stop mode</p> <ul style="list-style-type: none"> <li>• When the automatic backlash adjustment bit is set to "1", backlash movement is performed regardless of the moving direction when the backlash correction command is executed. When it is set to 0, move direction is judged and if there is a value of the movement destination in the correction direction (When the correction value is positive the CCW direction), move without performing backlash compensation movement.</li> <li>• When the soft limit state is set to "1", the soft limit switch is enabled.</li> <li>• When the limit switch stop mode is set to "1", it does sudden stop when the limit switch is detected. When it is set to "0", deceleration stops.</li> </ul>

x: 0/Channel A 1/Channel B , X: A/channel A B/channel B  
 (old): NPM2C-01 compatible command

Command	Explanation
(old) S4x5	Read various flags. Reply: RxS00HH HH: Refer to the command of S39x6.
FLxddd...	Set soft limit value of CW side to be used when soft limit is enabled. ddd...: -2,147,483,647 to +2,147,483,647 The number of digits and the sign are arbitrary.
(old) S5xFL±DDDDDDDD	±DDDDDDDD: Signed 7 digits integer
FL?x	Read the digital limit value on the CW side. Reply: ±ddddddd
(old) S4xFL	Reply: ±ddddddd Signed 7 digits integer
BLxddd...	Set soft limit value of CCW side to be used when soft limit is enabled. ddd...: -2,147,483,647 to +2,147,483,647 The number of digits and the sign are arbitrary.
(old) S5xBL±DDDDDDDD	±DDDDDDDD: Signed 7 digits integer
BL?x	Read the digital limit value on the CCW side. Reply: ±ddddddd
(old) S4xBL	Reply: ±ddddddd Signed 7 digits integer

## 6-8 Other commands

Command	Explanation
VER?	Read the version information of the built-in firmware. Reply: 1.03 13-10-16 UPM2C-01 etc.
VERH?	Read the version information of the hardware. Reply: HD-VER etc.
FROM?	Read the flash ROM for saving the firmware currently in use. Reply: FROM0/1
FROM0 FROM1	Set the flash memory to be used out of the two firmware save flash ROMs. After inputting this command, restart the power supply or start up with the firmware of the flash ROM selected by inputting the REST command.
REST	Reset the UPM2C-01. This is the same operation as unplugging the USB cable and inserting it again.
REST_INIT	In addition to executing the REST command, return the parameter to the factory setting.

## 6-9 The initialization of setting data

Input the "REST\_INIT" command, various setting data of "UPM2C-01" are initialized to the following values. Data to be set is common to channels A and B. If the motor stops working, save the set value and then initialize the setting data with the above command, it will operate normally.

Current position	0	HOLD OFF signal	ON (Signal output at stop)
Speed	MSPD	Acceleration/ Deceleration form	Trapezoidal acceleration/ deceleration
HSPD	3700	Pulse output mode	Pulse-Pulse
HSPD(code)	48	Limit switch	Enable
MSPD	650	Soft LS	Disable
MSPD(code)	16	Contact of LS	All N.O
LSPD	10	Stop mode of LS	Deceleration stop
LSPD(code)	1	Automatic backlash adjustment	Enable
RATE	13	CCW soft LS	-1,000,000
Backlash value	+100	CW soft LS	1,000,000

## 7 Continuous drive mode (from V1.03)

---

### 7-1 About Continuous drive mode

In this mode, by previously inputting data on the travel distance and the time required for traveling, it is possible to perform continuous operation while changing the motor speed of both axes at the minimum time of 10 ms unit at any time according to the set distance and time.

Moving the motor every 1000 ms to make a reciprocating motion, or by performing the movement continuously for 10 pulses, 20 pulses and finely specifying the movement amount, it is possible to perform curvilinear motion in a pseudo manner.

It is recommended to operate the acceleration / deceleration mode at constant speed operation when finely specifying movement amount.

Acceleration / deceleration mode can be changed by "SETMT" command (See paragraph 6.4).

Major specification of this Continuous drive mode

- \* The number of data that can be entered is 1024. The execution order is the ascending order of the data number.
- \* Movement amount can be specified both absolute value (ABS movement) and relative value (REL movement).
- \* It operates while changing the moving speed at any time within the range not exceeding the current speed from the specified time and distance each time each movement.
- \* The range of data used for driving continuous motion can be specified each time it moves.
- \* Data can be the collective input in a CSV format file, and also output.
- \* Temporary interruption of operation is possible.
- \* When a motor stop command (ASSTP etc.) is input during continuous drive operation the motors on both axes stop and the continuous operation is terminated.
- \* If the motor is in operation at the start of operation, up to 10 data numbers that were being executed at that time will be recorded. After that, it waits until it becomes operable.

### 7-2 About data format

Data required for continuous drive operation is expressed in the following format.

a,b,c,d example) 100,50,80,80

a: Data number. 1 to 1024 is the input range.

b: Traveling time (msec).

By the time set, change the speed within the range that does not exceed the current setting speed so that the movement of both motors is just completed.

For the data set in the example, it is temporarily changed to (about 1,600 pps) to be able to move 80 pulses in 50 ms. If the set speed is less than 1,600 PPS, it moves at the set speed.

It can be set from 0 to 65,535 (msec), but less than 10 msec is truncated.

When 0 is set, this data number is ignored and the next data number is referenced.

c: It is a movement pulse of A axis. It can be set from -32,768 to +32,767.

d: It is a movement pulse of B axis. It can be set from -32,768 to +32,767.

Whether the value of the movement pulse is absolute value specification or relative value designation is specified with the command.

"SQMODE ABS" specifies absolute value specification and "SQMODE REL" specifies relative value.

If you do not move the axis with that data, please set 0 for movement pulse if relative value is specified, and same value as previous data if absolute value designation.

### 7-3 Move mode setting

Use the following command to set whether the movement pulse value is absolute position or relative position.

Command	explanation
SQMODE?	It reads whether absolute value specification or relative value designation is made for pulse value of continuous movement data. reply: ABS/REL ABS: Absolute value specification REL: Relative value specification
SQMODE ABS SQMODE REL	Set pulse value of continuous movement data to absolute value specification or relative value specification. reply: -

### 7-4 Data input

To transmit continuous drive data to UPM2C-01 there are two methods, one for data transmission and the other for csv format file transmission.

Command	explanation
SQDATA a,b,c,d	Enter 1 continuous data for continuous movement data. Please use it to correct some data etc. For a, b, c, d please refer to "About data format" in the previous section.
SQDATA?m	Read continuous movement data of data number m. reply: b,c,d
SQDATA?m,n	Read continuous movement data from data number m to n. This read command is valid only while both A and B axis motors are stopped. reply: m,b,c,d n,b,c,d

When sending data collectively in csv format, do it in the following format.  
Please transmit the file when both A and B axis motors are stopped.

```
SQMODE REL
PS00
PS10
SQDATA ENTER
1,10,30,30
2,10,30,30
3,10,31,31
:
498,20,290,290
499,20,300,300
500,20,300,300
SQEND
```

It is possible to write a setting command arbitrarily on the line above SQDATA ENTER.

With this instruction, UPM2C-01 enters the data reading priority mode.  
The beginning of data contents.

The end of data contents.  
Please be sure to add it to the last line. (Cancels data reading priority mode)

Before reading "SQEND" on the last line, if it is disconnected due to some cause, please stop sending / receiving commands for about 3 seconds.

Data input example

```
SQMODE REL
SQDATA
1,100,20,20
SQDATA
2,200,30,30
SQDATA 3,0,20,20
SQDATA
4,100,20,20
```

When inputting the data on the left and executing from No. 1 to No. 4, both A and B axes will move 20 pulses at a speed of about 200 pps.

If the motors on both axes are stopped, No. 2 will be executed and 30 pulses will be moved at a speed of about 150 pps on both shafts.

Number 3 is omitted because the standby time is 0, and No. 4 is executed immediately after confirming the motor stop.

This operation is completed and the continuous movement operation is over.

### 7-5 Continuous motion control

After inputting the continuous drive data, the operation is started with below commands.

Command	explanation
SQSTART a,b	Continuous drive is started within the range of data numbers a to b. a <= b, 1 <= a <= 1024, 1 <= b <= 1024 reply: -
SQPAUSE ON SQPAUSE OFF	By SQPAUSE ON during continuous drive operation, wait for completion of currently executing data and suspend operation temporarily. By SQPAUSE OFF, operation resumes. During continuous drive pause, the continuous operation ends with a stop command such as "SSTP0". reply: -

Command	explanation
SQSTS?	<p>It confirms the state during continuous drive operation.</p> <p>reply:</p> <p>DRIVING at No. xx Continuous driving is in progress. xx: Data number being executed</p> <p>PAUSE at No. xx Continuous driving is in pause.</p> <p>STOP (*1) Continuous driving is not executed.</p> <p>*1: If it is not continuous driving operation even during motor operation, this will be displayed.</p>
SQERR?	<p>It checks error information during continuous driving.</p> <p>xx: Error count</p> <p>a, b, .. i, j: Data number where the error occurred.</p> <p>reply:</p> <p>NO ERROR. There is no error. Record the first ten.</p> <p>BUSY ERROR at No. a,b,....,i,j 1 to 10 errors.</p> <p>USY ERROR xx times at No. a,b,....,i,j and more. More than 11 errors.</p>

### 7-6 Setting data initialization

By inputting the "REST\_INIT" command, the continuous drive related data of UPM2C-01 is initialized to the following values.

At this time, both the movement time and pulse value are set to 0 for continuously driven data.

Normally, data is held by battery backup.



## 8 Dual-Axis Complementary Drive

### 8-1 Outline

The dual-axis complementary drive is a function which drives two motors as drawing a line, an arc, and a circle on the X-Y plane. Motor-A, motor-B corresponds X-coordinate, Y-coordinate respectively.


The motion parameter (e.g. velocity and acceleration) of all of motor A is applied to motor-B.

To stop motors, STOP command to either motor-A or motor-B is effective.


### 8-2 Line Approximation Movement

Command	<i>COaLN01±xxx/±yyy</i>
Description	<p>Move to the destination from the current position linearly.</p> <p>- Parameters a: Data property    A / Absolute    R / Relative</p> <p>xxx: X-coordinate of the destination or distance of X direction.</p> <p>yyy: Y-coordinate of the destination or distance of Y direction.</p>
Example	<i>COALN01+10000/-5000</i>

Absolute position movement



Relative position movement




●: Current position    ○: Destination


### 8-3 Complementary Arc Movement

Command	$C0aCd01\pm xxx/\pm yyy/\pm uuu/\pm vvv$
Description	<p>Move to the destination with drawing an arc. Radius is the distance between the current position and the center point (u,v).</p> <p>If the destination isn't on the circle, the position moves to the nearest point to the destination, then line approximation movement operation to the destination. When the destination and the current position is same, true circle movement.</p> <p>- Parameters  a: Data property    A / Absolute    R / Relative  d: Direction to the destination    P/CW    N/CCW</p> <p>xxx:    X-coordinate of the destination or relative position on the X axis from the current position  yyy:    Y-coordinate of the destination or relative position on the Y axis from the current position  uuu:    X-coordinate of the center point or relative position on the X axis from the current position  vvv:    Y-coordinate of the center point or relative position on the Y axis from the current position</p> <p>- Parameter range:  Absolute position (a = A) : -2,147,483,647 to +2,147,483,647  Relative position (a = R) : -8,388,607 to +8,388,607</p>
Example	<p><math>C0ACN01+0/+1000/+0/+500</math></p> <p>Moves to (0,+1000) with drawing an arc counterclockwise on the circle whose radius is the current position and (0,+500).</p>

Absolute position movement



Relative position movement




●:Current position    ▲:Center point    ○:Destination


## 8-4 Waypoint Complimentary Arc Movement

Command	$C0aAC01 \pm xxx / \pm yyy / \pm uuu / \pm vvv$
Description	<p>Move to the destination with drawing an arc which has a waypoint (u,v).</p> <p>If you need true circle movement by specifying the current position as the destination, please use the C0aCC... command as stated later.</p> <p>- Parameters a: Data property    A / Absolute    R / Relative</p> <p>xxx: X-coordinate of the destination or relative position on the X axis from the current position yyy: Y-coordinate of the destination or relative position on the Y axis from the current position uuu: X-coordinate of the waypoint or relative position on the X axis from the current position vvv: Y-coordinate of the waypoint or relative position on the Y axis from the current position</p> <p>- Parameter range: Absolute position (a = A) : -2,147,483,647 to +2,147,483,647 Relative position (a = R) : -8,388,607 to +8,388,607</p>
Example	<p><math>C0AAC01+0/+1000/+500/+0</math></p> <p>Move (+ 500, 0) from the current position and moves with drawing an arc toward (0, + 1000).</p>

Absolute position movement



Relative position movement




●:Current position    ▲:Waypoint    ○:Destination


### 8-5 True circle movement with complemented waypoint

Command	$C0aCC01\pm xxx/\pm yyy/\pm uuu/\pm vvv$
Description	<p>Return to the current position with drawing the circle passing by waypoint 1 (u,v) and waypoint 2 (x,y) sequentially.</p> <p>- Parameters  a: Data property    A / Absolute    R / Relative</p> <p>uuu: X-coordinate of the waypoint1 or relative position on the X axis from the current position  vvv: Y-coordinate of the waypoint1 or relative position on the Y axis from the current position  xxx: X-coordinate of the waypoint2 or relative position on the X axis from the current position  yyy: Y-coordinate of the waypoint2 or relative position on the Y axis from the current position</p> <p>- Parameter range:  Absolute position (a = A) : -2,147,483,647 to +2,147,483,647  Relative position (a = R) : -8,388,607 to +8,388,607</p>
Example	<p><math>C0RCC01+500/+500/+0/+1000</math></p> <p>Go through the two points (0, 1000) and (500, 500) sequentially to the current position with the current position as (0, 0).</p>

Absolute position movement



Relative position movement



●:Current position    ▲:Waypoint1    △:Waypoint2

## 9 Firmware version up

---

You can perform firmware upgrade of UPM2C-01 via USB communication line.

To keep safety you had better pull out the cables between unit and motor driver, or put off the power line of motor drivers.

In addition, the setting including the pulse value is initialized after firmware version up.

Please save the parameter of the UPM2C-01 by using trial software or please write out the parameter from setting as necessary.

You can find the file transmit for firmware version up software and its user's manual in the product web page.

File transmit for firmware version up software (for windows)

[http://www.tsuji-denshi.co.jp/download/lan\\_rs\\_file\\_send.EXE](http://www.tsuji-denshi.co.jp/download/lan_rs_file_send.EXE)

User's manual (PDF)

[http://www.tsuji-denshi.co.jp/manual\\_pdf/pm16c\\_04xd\\_vup\\_soft.pdf](http://www.tsuji-denshi.co.jp/manual_pdf/pm16c_04xd_vup_soft.pdf)

The below explanation is how to perform firmware version up by using LAN communication and Tera Term (free software).

1. Download the text file for version upgrade from Tsuji-Electronics HP.  
Firmware update information and update files are informed this page.  
[http://www.tsuji-denshi.co.jp/support/ver\\_11.html](http://www.tsuji-denshi.co.jp/support/ver_11.html)
2. Launch the program "Tera Term".
3. Click File -> New connection, and select com port for UPM2C-01 is connected.
4. Click SETUP -> Terminal, and set New-Line code to CR+LF both Receive and Transmit. Select Local Echo checkbox, and click OK button and exit setting.
5. Send the command "VER?", and if there is reply, the connection is OK.
6. Click File -> Send file, and appear send file select window. Choose the version up file that you have prepared at section 1(UPM2C\_01\_V1.xx.S).
7. "ACCESS" lamp is blinking while downloading firmware. If blinking is more quickly, this is the sign of writing new firmware to ROM. If stop blinking, this is the sign of firmware update is completed.
8. Disconnect the UPM2C-01 communication and pull USB cable out from UPM2C-01 or send "REST" command. Insert USB cable again, and start with new firmware.

UPM2C-01 contains two flash rom for writing firmware. The newer firmware is written on the unused flash rom, and will be selected new rom on next startup.

You can know which rom is current using by "FROM?" command, reply is "FROM0" or "FROM1". If you are going to compare the operation for firmware version difference, you can select the firmware for next startup with "FROM0" or "FROM1" command.

If trouble occurred in download process and failed to connect to UPM2C-01, you can restore with first written firmware on CPU-ROM. The restore process is below.

1. Pull USB cable and AC adaptor cable out from UPM2C-01, and remove the top plate.
2. Turn ON dip switch 1 and OFF dip switch 2 at DSW1 on circuit board.
3. Connect USB cable, and blink quickly “ACCESS” lamp. If stop blinking, pull cable out.
4. Turn OFF dip switch 1 and 2, and connect USB cable again.
5. UPM2C-01 turns on with factory firmware version.

## 10 Data1 “SPEED code”

The SPEED CODE used in the command to set the drive speed, but the speed corresponding to each code is undermentioned.

SPEED code Table (unit: PPS/Pulse Per Second)

No.	PPS	No.	PPS	No.	PPS	No.	PPS	No.	PPS	No.	PPS
0	5	43	3200	86	7500	129	15580	172	30680	215	58600
1	10	44	3300	87	7600	130	15770	173	31250	216	59400
2	25	45	3400	88	7700	131	15970	174	31850	217	60200
3	50	46	3500	89	7800	132	16180	175	32470	218	61100
4	75	47	3600	90	7900	133	16400	176	33110	219	61900
5	100	48	3700	91	8000	134	16610	177	33780	220	62800
6	150	49	3800	92	8200	135	16830	178	34480	221	63600
7	200	50	3900	93	8400	136	17060	179	35210	222	64500
8	250	51	4000	94	8600	137	17240	180	35970	223	65400
9	300	52	4100	95	8800	138	17420	181	36500	224	66300
10	350	53	4200	96	9000	139	17600	182	37040	225	67200
11	400	54	4300	97	9200	140	17800	183	37600	226	68100
12	450	55	4400	98	9400	141	17990	184	38170	227	69100
13	500	56	4500	99	9600	142	18180	185	38760	228	70000
14	550	57	4600	100	9800	143	18380	186	39370	229	71000
15	600	58	4700	101	10000	144	18660	187	40000	230	72000
16	650	59	4800	102	10200	145	18940	188	40500	231	73000
17	700	60	4900	103	10400	146	19230	189	41100	232	74000
18	750	61	5000	104	10600	147	19530	190	41600	233	75000
19	800	62	5100	105	10800	148	19840	191	42200	234	76000
20	900	63	5200	106	11010	149	20160	192	42800	235	77100
21	1000	64	5300	107	11210	150	20500	193	43400	236	78100
22	1100	65	5400	108	11410	151	20830	194	44000	237	79200
23	1200	66	5500	109	11600	152	21190	195	44600	238	80300
24	1300	67	5600	110	11800	153	21550	196	45200	239	81400
25	1400	68	5700	111	11990	154	21930	197	45800	240	82500
26	1500	69	5800	112	12200	155	22320	198	46400	241	83700
27	1600	70	5900	113	12400	156	22730	199	47100	242	84800
28	1700	71	6000	114	12600	157	23150	200	47700	243	86000
29	1800	72	6100	115	12790	158	23590	201	48400	244	87200
30	1900	73	6200	116	12990	159	24040	202	49100	245	88400
31	2000	74	6300	117	13200	160	24510	203	49700	246	89600
32	2100	75	6400	118	13400	161	25000	204	50400	247	90800
33	2200	76	6500	119	13620	162	25510	205	51100	248	92100
34	2300	77	6600	120	13810	163	26040	206	51800	249	93300
35	2400	78	6700	121	14000	164	26600	207	52500	250	94600
36	2500	79	6800	122	14200	165	27170	208	53300	251	95900
37	2600	80	6900	123	14400	166	27620	209	54000	252	97300
38	2700	81	7000	124	14620	167	28090	210	54700	253	98600
39	2800	82	7100	125	14830	168	28570	211	55500	254	100000
40	2900	83	7200	126	15010	169	29070	212	56300		
41	3000	84	7300	127	15200	170	29590	213	57000		
42	3100	85	7400	128	15390	171	30120	214	57800		

# 11 Data2 “Acceleration / Deceleration rate”

---

The acceleration / deceleration rate is a coded value from 0 to 115, but the acceleration / deceleration values corresponding to each rate data are undermentioned.

Rate Data Table (unit: ms/1000pps “The time it takes to reach the speed of 1000 pps”)

No.	RATE	No.	RATE	No.	RATE	No.	RATE	No.	RATE	No.	RATE
0	1000	20	150	40	22	60	3.3	80	0.47	100	0.068
1	910	21	130	41	20	61	3	81	0.43	101	0.062
2	820	22	120	42	18	62	2.7	82	0.39	102	0.056
3	750	23	110	43	16	63	2.4	83	0.36	103	0.051
4	680	24	100	44	15	64	2.2	84	0.33	104	0.047
5	620	25	91	45	13	65	2	85	0.3	105	0.043
6	560	26	82	46	12	66	1.8	86	0.27	106	0.039
7	510	27	75	47	11	67	1.6	87	0.24	107	0.036
8	470	28	68	48	10	68	1.5	88	0.22	108	0.033
9	430	29	62	49	9.1	69	1.3	89	0.2	109	0.030
10	390	30	56	50	8.2	70	1.2	90	0.18	110	0.027
11	360	31	51	51	7.5	71	1.1	91	0.16	111	0.024
12	330	32	47	52	6.8	72	1	92	0.15	112	0.022
13	300	33	43	53	6.2	73	0.91	93	0.13	113	0.020
14	270	34	39	54	5.6	74	0.82	94	0.12	114	0.018
15	240	35	36	55	5.1	75	0.75	95	0.11	115	0.016
16	220	36	33	56	4.7	76	0.68	96	0.1		
17	200	37	30	57	4.3	77	0.62	97	0.091		
18	180	38	27	58	3.9	78	0.56	98	0.082		
19	160	39	24	59	3.6	79	0.51	99	0.075		



## 12 Performance and Specification

Power	Supply DC 5 V from USB port, or supply DC + 12 V from an optional AC adapter (T3168AC).		
IN/OUT	Control motor	2 motors can be controlled	
	Capability	2 motors can be controlled simultaneously.	
	Control output	CW and CCW (+5V 8mA: line driver) for each motor driver.	
		*HOLD OFF signal for each motor driver (Open collector output and +5V common)	
	Output frequency	1 to 5MPPS	
	Control pulse	0 to $\pm 2,147,483,647$	
	Acceleration and Deceleration rate	1000 to 0.0125 ms/kHz	
	Acceleration and Deceleration form	Constant and Trapezoid, S shape form	
	Output specification	2 pulses (pulse - pulse) / 1 pulse (pulse - direction)	
	Pulse out connector	Dsub9S(F)	
	Limit switch input	CW-LS, CCW-LS, HOME-LS 12V 5mA (minus common) for each control motor. Using the AC adapter, power supply +12V for censer is available (MAX 0.5A).	
Limit switch connector	Dsub9P(M)		
Stepping mode	SCAN MODE	Continuously stepping the selected motor.	
	ABS IDX MODE	Move the selected motor to the set value.	
	REL IDX MODE	Move the selected motor by the set value.	
Communication port	USB	Communication conector: USB-B, USB1.1, USB 2.0 compatible. Communication for virtual Com port driver similar to serial port.	
Case and Weight	Stationary type (40H×170W×100D) 350g		

\* The output of the HOLD OFF signal of the product shipped after January 2016 has been changed to open collector. (Products for which the response of VERH is HD-VER 2 etc.) The product of HD-VER 1 is the same line driver output as CW and CCW, but the same type of cable is available.

For the further information, feel free to ask us.

Tsuji Electronics Co., Ltd.  
 TEL: +81-(0)29-832-3031 FAX: +81-(0)29-832-2662  
 E-mail: info2@tsuji-denshi.co.jp  
 URL: <http://www.tsujicon.jp>  
 3739, Kandatsu-machi, Tsuchiura-city, Ibaraki 300-0013, Japan